



INSTALLATION INSTRUCTIONS FOR WALL & CEILING MOUNT KIT P/N: 4401, 380 XP EXPLOSION PROOF 2 AND 3 LAMP FLUORESCENT LIGHT FIXTURES

1. REMOVE (2) 1/2" NPT RECESSED HEAD PLUGS FROM FIXTURE ENDS.
2. ATTACH WALL/CEILING BRACKETS TO HOUSING ENDS WITH (2) 1/2" NPT BOLTS.
BRACKETS CAN BE ATTACHED TO THE TOP HUBS AS WELL AS THE 45 DEGREE HUBS FOR ANGLED MOUNTING.
NOTE: LUBRICATE ALL THREADS WITH PETROLATUM
3. FIXTURE ASSEMBLY IS TO BE MOUNTED TO WALL OR CEILING USING 1/2" BOLTS BY OTHERS.
4. RE-LAMPING CAN BE DONE FROM EITHER END BY REMOVING 1/2" NPT BOLTS OR UNFASTENING BRACKET FROM STRUCTURE, AS LONG AS SAFETY CABLE IS AT THE END TO BE DROPPED.
5. REMOVE 1/4-20 BOLT THAT ATTACHES REFLECTOR BRACKET TO THE END OF THE FIXTURE AND REPLACE WITH EYEBOLT FROM SAFETY CABLE/CHAIN.
6. INSTALLATION OF LIGHT FIXTURE WALL AND CEILING MOUNT KIT IS NOW COMPLETE.
7. THIS FIXTURE SHOULD BE INSTALLED BY QUALIFIED TECHNICIANS IN STRICT ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ANY LOCAL REQUIREMENTS.







